

Mussle Power ! (a.k.a Mussel Paua)

Yile Ying @ VUW

08/06/2017



 yile.ying@gmail.com


Have you ever ... ?




Source: Google Image search.

A computer program allows you to...

- **Control your computer using muscles**
 - Play video games! Yeah!
 - Do whatever you want.
- **Monitor muscle activities**
 - How many times?
 - How long?
 - How strong?




Three devices



Souce: Google Image search.


MyoWare Muscle Sensor -> sEMG Signal



Source: Advancer Technologies. (2015). *MyoWare™ Muscle Sensor (AT-04-001) Datasheet*. Retrieved June 2017 from: https://cdn.sparkfun.com/assets/learn_tutorials/4/9/1/MyoWareDatasheet.pdf 5


sEMG Signal is the Superposition of Motor Unit Signals

Range from 20Hz~150Hz







Source: Konrad, P. (2005). *The ABC of EMG: A Practical Introduction to Kinesiological Electromyography*. Retrieved June 2017 from: <https://hermanwallace.com/download/The ABC of EMG by Peter Konrad.pdf>

Two Types of Output Signals







Raw Signal VS MyoWare Signal



* Sampling Rate: 1000Hz


The Usage of the Raw Signal

- e.g. Muscle Fatigue






Real-time Muscle Condition Monitoring Program





MyoWare Signal



Raw Muscle Signal



Raw Signal VS MyoWare Signal



* Sampling Rate: 1000Hz

The program:

Calibration Instruction:

1. Keep your muscle relaxed.
2. Press 'Calibrate' button to start.
3. Keep your muscle relaxed and wait for around 5 seconds.
4. Press 'Calibrate' button again to stop.
5. You can repeat the process 2-4 again if you moved your muscle or the sensor during the calibration.
6. Press the 'Exit' button when you are happy with your threshold.


Calibrate

My Threshold

1

EXIT

My Muscle Signal



Instructions:

1. Type in the Sampling Rate (recommend 10~30Hz).
2. Choose the key or mouse action you want to simulate.
3. Run the program.
4. Calibrate your muscle sensor in the pop-up window.
5. Open the game you want to play and enjoy! ^-^

Sampling Rate (Hz)

10

Virtual Key

SPACE

STOP

Total Contraction Times

0

Current Muscle Power

0

Max Muscle Power

0

Current Duration

0


Max Duration

0


Total Duration

0


Muscle Signal




Let us try!



Calibration



Main Part



Further development!

- **Simulate more computer actions at one time**
 - not only one-button game!
 - playing music!
 - ...
- **Use the raw signal instead of the MyoWare signal**
 - combine the muscle fatigue monitoring
 - less lag
 - ...
- **A more suitable game for physical recovery**
 - accommodate different patients